In this lab, a <u>Shazam (http://bit.ly/1fvTDIQ)</u>-similar system is implemented. An acoustic fingerprint of a song is generated by hashing the frequency and time information in the spectrogram. A fingerprint of a snippet is later generated and searched through the database of hashes. A high number of matches is found if the snippet comes from the corresponding song.

Shazam: Audio Recognition System

As usual, we set the pylab inline option and import necessary modules.

```
In [300]: import numpy as np
import matplotlib.pyplot as plt
import matplotlib.mlab as mlab
from scipy.ndimage.filters import maximum_filter # find the peaks in
from scipy.ndimage.morphology import (generate_binary_structure,iten
from pydub import AudioSegment #read wav file.
import hashlib # to generate hash from the frequency and time inform
%matplotlib inline
```

We define a function called readAudioFile to read the **wav** file. *limit* is the number of seconds from the beginning of the song we would like to read. If *limit* is None, readAudioFile returns the data for the whole song.

```
In [301]: def readAudioFile(filename, limit= None):
    audiofile = AudioSegment.from_wav(filename)
# print audiofile
if limit:
    audiofile = audiofile[:limit * 1000]
    data = np.fromstring(audiofile._data, np.int16)
    channels = []
    for chn in xrange(audiofile.channels):
        channels.append(data[chn::audiofile.channels])
    return channels, audiofile.frame_rate, audiofile
```

We will implement the Shazam paper

(http://www.ee.columbia.edu/~dpwe/papers/Wang03-shazam.pdf). We will refer to figures in this paper. Next we define two functions:

- 1. **get_2D_peaks**: Find the peaks in the spectrogram. Refer to figure 1B of the paper. The set of peaks of the spectrogram is also called the constellation map.
- 2. **generate_hashes**: Generate the hashes from the constellation map. See figure 1C and 1D. The struture of the hashes is [f1:f2:delta t]:t1. Then we call the

hashlib function sha1 to generate a single number for our hash. For this demo, I keep the first 25 values of the hash.

Question: does the accuracy of the algorithm increase or decrease if you increase the number of hashes to keep? It would increase because there is more data per song, but only to an extent.

```
def get 2D peaks(arr2D, plot,amp min = 10):
In [302]:
               struct = generate binary structure(2,1)
               neighborhood = iterate structure(struct, 20)
               detected peaks = maximum filter(arr2D, footprint = neighborhood
               amps = arr2D[detected peaks]
               j,i = np.where(detected peaks)
               amps = amps.flatten()
               peaks = zip(j,i, amps)
               peaks filtered = [x \text{ for } x \text{ in peaks if } x[2] > amp min]
               frequency idx = [x[1] \text{ for } x \text{ in } peaks \text{ filtered}]
               time idx = [x[0] for x in peaks filtered]
               if plot:
                   fig, ax = plt.subplots()
                   ax.imshow(arr2D)
                   ax.scatter(frequency idx, time idx)
                   ax.set xlabel('Time')
                   ax.set ylabel('Frequency')
                   ax.set_title("Spectrogram")
                   plt.gca().invert yaxis()
                   plt.axis('tight')
               return zip(frequency idx, time idx)
           def generate hashes(peaks, fan value = 10, len hash = 25):
               fingerprinted = set()
               for i in range(len(peaks)):
                   for j in range(fan value):
                        if (i + j) < len(peaks) and not (i, i + j) in fingerprir</pre>
                            freq1 = peaks[i][1]
                            freq2 = peaks[i + j][1]
                            t1 = peaks[i][0]
                            t2 = peaks[i + j][0]
                            t delta = t2 - t1
                            if t delta >= 0:
                                h = hashlib.shal("%s|%s|%s" % (str(freq1), str(1
                                yield (h.hexdigest()[0:len hash], t1)
                            fingerprinted.add((i, i + j))
```

The following function **fingerpint** returns the hashes of an audio file.

Now we are ready to extract and save the fingerprints. First we read the audio file from the wav folder. You can input your own wav file there. Define sampling rate, window size, overlap ratio between consecutive frames. pydub (https://github.com/jiaaro/pydub/) can read mp3 file, but you need to configure ffmpeg. You might do that on your own computer.

```
In [304]: channels, framerate, data = readAudioFile('data/JonBoden.wav')
Fs = 44100 # sampling freq
wsize = 4096 # window size
wratio = 0.5 # overlap ratio
fan_value = 10 #number of target points in the frequency domain to pamp_min = 25 # minimum amplitude of the peak.
plot = False
for samples in channels:
    hashes = fingerprint(samples, Fs, wsize, wratio, fan_value, amp_
```

For easy visualization and explanation, we will convert our hases into a dictionary of the form: **dict[hash] = t1**. Dictionaries consist of pairs of **keys** and their corresponding **values**. We use the hashes as keys and the time of the hash as value. Since different segments from the audio file can produce the same hash, one key might correspond to multiple values (multiple starting times t1). We use the *defaultdict* data structure to accomodate multiple-valued-single-key entries.

```
In [305]: from collections import defaultdict
def hashesToDict(hashesExcerpt):
    dataExcerpt = []
    for i in hashesExcerpt:
        dataExcerpt.append(i)
    dictExcerpt = defaultdict(list)
    for hashString, t1 in dataExcerpt:
        dictExcerpt[hashString].append(t1)
    return dictExcerpt
```

Now we convert the hashes to a dictionary called **dictOriginal**. **dictOriginal** contains all the hashes of the 'JonBoden.wav' song. The key is the hash and the value is the time. See figure 1D in the paper.

```
In [306]: dictOriginal = hashesToDict(hashes)
```

To implement searching, we could implement mySQL (mySQL (http://mysql-python.sourceforge.net/) databases. This provides a systematic approach to store, retrieve and search for hashes. mySQL requires a mySQL server, which adds a level of complexity to this project. For now, we only save the fingperprints into a file and later retrieve them if we need.

```
In [307]: import pickle
fileHandle = open("JonBoden.fp","wb") #wb: write binary
pickle.dump(dictOriginal, fileHandle)
```

Testing the System

Now we load the fingerprinted file back and store it as **dictOriginal**. You can fingerprint as many files as you want, then read all of them here.

```
In [308]: fileHandle = open("JonBoden.fp","rb")
dictOriginal = pickle.load(fileHandle)
```

Exercise 1. Write a function called readAudioFileExcerpt with three inputs. See the readAudioFile function above for guidance. The first input is the filename. The other two inputs are lowLimit and highLimit, which is used to read the audio file from lowLimit to highLimt seconds.

```
In [309]: def readAudioFileExcerpt(filename, lowLimit, highLimit):
    audiofile = AudioSegment.from_wav(filename)
    audiofile = audiofile[lowLimit * 1000:highLimit * 1000]
    data = np.fromstring(audiofile._data, np.int16)
    channels = []
    for chn in xrange(audiofile.channels):
        channels.append(data[chn::audiofile.channels])
    return channels, audiofile.frame_rate, audiofile
```


Excercise 2. Use your function to read the excerpt from the JonBoden.wav and generate the hashes from this snippet. Name the hahses **hashesExcerpt1**. Also, we've set the plot parameter to True to visualize the peaks of the spectrogram. What parameters in the **fingerprint** function affect the number of peaks?

In [310]: # write your code here.
read in the audio snippit from 40s to 50s
channelsExcerpt1, framerate, data = readAudioFileExcerpt('data/JonBo
plot = True # but now we want to visualize the peak (pass this as a

call the fingerprint function to generate the hashes.

for samples in channelsExcerpt1:

hashesExcerpt1 = fingerprint(samples, Fs, wsize, wratio, fan_val



Now we convert the **hashesExcerpt1** to a dictionary. We can call the **hashesToDict** function defined earlier.

```
In [311]: dictExcerpt1 = hashesToDict(hashesExcerpt1)
```


Excercise 3. Write a function to match the fingerprint of the excerpt to the original song. Return count and delta_k. Count is the number of matching hashes. delta_k is a list of offsets of the database song time and the snippet song time. See section 2.3 of the paper. Read also this document (http://www.tutorialspoint.com/python/python_dictionary.htm) on how to manipulate the dictionary.

```
In [312]:
          def match_fingerprint(dictExcerpt,dictOriginal):
               count = 0
               delta k = []
               for each hash in dictExcerpt.keys():
                   #print each hash
                   #break
                   if each_hash in dictOriginal:
                       count += 1
                       for each value in dictExcerpt.get(each hash):
                           delta k.append(np.subtract(dictOriginal.get(each has
               return count, [val for sublist in delta k for val in sublist]
In [313]:
          match fingerprint(dictExcerpt1, dictOriginal)
Out[313]: (167,
            [-177]
             938,
             2337,
             2518,
            937,
             677,
             1646,
             2949,
            3398,
             99,
             22,
            938,
             160.
             1258,
             2038,
            3565,
             398,
             538,
```

Let's count how many matches are found and plot the histogram of the offsets.

1/77

```
In [314]: #dictExcerpt1 = hashesToDict(hashesExcerpt1)
    count1, delta_k1 = match_fingerprint(dictExcerpt1, dictOriginal)
    if delta_k1:
        fig = plt.figure()
        ax = fig.add_subplot(111)
        numBins = 10
        ax.hist(delta_k1,numBins,color='green',alpha=0.8)
```



Exercise 4. Now load the second file, count the number of matches, and plot the histogram of the offsets.


```
In [325]: print len(delta_k1)
  decs = [int(x/10) for x in delta_k1]
  print decs
```

1200 [-18, 93, 233, 251, 93, 67, 164, 294, 339, 9, 2, 93, 16, 125, 203 356, 39, 53, 147, 155, 196, 316, 44, 56, 91, 126, 142, 197, 15, -12, 112, 156, 226, 28, 218, 57, 102, 6, 17, 19, 62, 81, 90, 9, 136, 160, 166, 239, 244, 249, 264, 307, 309, 325, 336, 346, 35 9, 273, 324, -13, 304, 59, 147, 160, 197, 295, 332, 93, -6, 30, 3 6, 45, 60, 82, 93, 97, 164, 174, 200, 271, 274, 287, 296, 301, 32 9, -10, 26, 32, 41, 57, 79, 90, 93, 161, 170, 197, 267, 270, 284, 292, 298, 325, -12, 24, 30, 39, 55, 77, 88, 91, 158, 168, 195, 26 5, 268, 282, 290, 296, 323, 8, 52, 74, 93, 153, 41, -11, 93, 181, 9, 15, 32, 43, 58, 78, 126, 146, 224, 268, 282, 327, 343, 365, -3, 93, 99, 201, -6, 90, 95, 197, -9, 88, 93, 195, 218, 149, 185, 93, 138, 282, 93, 33, 54, 57, 76, 93, 103, 161, 205, 50, 148, 153 252, 256, 259, 349, 356, 197, 201, 229, 257, -2, 7, 13, 19, 25, 5 6, 59, 93, 107, 121, 125, 128, 136, 146, 160, 170, 193, 197, 207, 228, 240, 250, 266, 289, 292, 328, 346, 355, 359, -13, -3, 2, 9, 4, 46, 49, 83, 97, 110, 114, 118, 125, 136, 150, 160, 183, 186, 1 7, 218, 229, 240, 256, 278, 281, 317, 335, 345, 348, 84, 197, 201 288, 292, 323, 0, 69, 96, 128, 139, 174, 199, 232, 242, 296, 310, 339, -2, 67, 93, 126, 137, 172, 197, 229, 240, 294, 308, 336, 162 98, 202, 262, 339, 307, 254, 35, 93, -17, -10, -3, 8, 24, 30, 36, 44, 64, 67, 71, 126, 128, 150, 153, 171, 186, 215, 222, 232, 251, 258, 262, 279, 282, 284, 293, 296, 321, 327, 333, 335, 342, 347, 05, 201, 100, 196, 265, 93, 189, 197, 292, 49, 93, 10, 128, 268, 87, 337, 339, 36, 93, 213, 297, 302, 133, 205, 263, 266, 277, 291 305, 319, 35, 197, 55, 90, 93, 149, 159, 195, 254, 263, 280, 358, 126, 197, 230, 268, 298, 93, 93, 270, 321, 90, 93, 306, 120, 276, 283, 306, 347, 10, 34, 46, 93, 96, 200, 254, 310, 342, 351, 357, 7, 31, 44, 91, 93, 197, 251, 307, 339, 348, 354, 198, 93, 103, 19 7, 251, 347, 84, 93, 187, 241, 338, 24, 192, 93, 112, 259, 356, 3 6, 127, 180, 36, 45, 52, 54, 63, 70, 84, 99, 125, 149, 151, 158, 74, 188, 221, 234, 255, 262, 290, 297, 354, 93, 151, 20, 82, 30, 187, 197, 225, 278, 287, 122, 148, 226, 247, 130, -7, 6, 20, 6, 65, 93, 118, 121, 126, 151, 156, 192, 208, 211, 225, 232, 237, 240, 251, 287, 289, 352, -3, 227, 71, 203, 197, 93, 93, 197, 246, 293, 301, 341, 343, -15, 103, 146, 221, 255, 314, 318, 325, 93, 2 9, 93, 128, 192, 197, 237, 323, 328, 2, 10, 16, 22, 25, 45, 58, 6 2, 92, 105, 126, 148, 162, 193, 196, 200, 228, 263, 291, 351, -9, -1, 4, 10, 14, 34, 46, 50, 81, 93, 114, 137, 151, 181, 184, 188, 16, 252, 280, 339, 104, 109, 207, 288, 86, 91, 189, 270, 27, 2, 81, 93, 98, 133, 140, 166, 201, 213, 232, 258, 295, 298, 310, 31, 361, 23, 54, 58, 77, 89, 93, 128, 136, 161, 197, 209, 228, 25 3, 291, 294, 306, 327, 357, 44, 80, 106, 115, 118, 122, 127, 148, 196, 206, 210, 219, 226, 239, 245, 322, 327, 332, 336, 344, 2, 64 132, 167, 199, 235, 244, 298, 347, 353, 364, 371, 213, 334, 10, 1 9, 134, 155, 263, 274, 288, 308, 317, 349, 93, 116, 119, 156, 197 222, 241, 285, 342, 162, 167, 197, 255, 308, 38, 65, 77, 93, 103, 116, 130, 133, 144, 165, 169, 177, 181, 183, 197, 204, 225, 234,

82, 287, 303, 356, 31, 59, 70, 87, 97, 110, 124, 126, 138, 158, 1

3, 170, 174, 177, 191, 197, 219, 228, 275, 281, 297, 350, 27, 55, 67, 83, 93, 106, 120, 122, 134, 154, 159, 166, 170, 173, 187, 194 215, 224, 271, 277, 293, 346, 84, 141, 180, 349, -1, 57, 93, 6, 1 8, 52, 93, 257, 259, 285, 215, 259, 264, 278, 312, 338, 20, 23, 1 7, 197, 93, 33, 195, 61, 80, 93, 165, 315, -3, 120, 119, 222, 231 278, 342, 367, 104, 184, 259, 279, 93, 174, 248, 269, 5, 123, 195 232, 259, 289, 294, 93, 93, 93, 4, 63, 111, 184, 265, 101, 122, 1 7, 93, 197, 82, 185, 261, 264, 305, 310, 0, 3, 23, 30, 48, 95, 13 0, 153, 197, 223, 245, 255, 282, 289, 299, 321, 336, 352, 358, 36 3, 296, 16, 19, 52, 156, 197, 260, 278, 286, 304, 350, 44, 266, 1 7, 139, 196, 346, 93, -18, 16, 58, 6, 26, 31, 40, 74, 93, 104, 11 1, 141, 163, 174, 215, 284, 303, 331, 344, 349, -4, 16, 21, 30, 6 4, 83, 93, 101, 130, 153, 164, 204, 274, 293, 321, 333, 339, 128, 197, 293, 93, 154, 93, 110, 13, 41, 93, 106, 209, 255, 267, 287, 08, 320, 324, 331, 350, 353, 25, 38, 49, 72, 84, -11, -6, -4, -2, 2, 5, 24, 29, 34, 59, 68, 93, 111, 122, 136, 146, 162, 166, 171, 80, 212, 216, 222, 232, 239, 246, 248, 263, 268, 277, 294, 307, 3 1, 328, 336, 342, 364, 57, 66, 154, 93, 107, 142, 185, 280, 343, 18, -19, -15, -13, -11, -6, 2, 6, 10, 12, 24, 33, 36, 42, 48, 71, 80, 93, 99, 128, 175, 181, 187, 197, 204, 221, 229, 231, 253, 258 274, 297, 317, 323, 326, 328, 332, 347, -22, -18, -16, -13, -9, 1, 3, 7, 9, 21, 30, 33, 39, 46, 68, 78, 90, 96, 125, 172, 178, 18 4, 194, 201, 218, 226, 229, 250, 255, 271, 294, 314, 321, 323, 32 5, 330, 344, 2, 44, 70, 148, 159, 208, 189, 279, 116, 125, 325, 2 2, 93, 93, 101, 81, 88, 93, 93, 158, 93, 123, 217, 67, 303, 178, 37, 39, 93, 107, 197, 238, 326, 35, 89, 103, 193, 234, 322, 93, 1 8, 197, 271, 285, 102, 197, 266, 280, 93, 116, 130, 25, 60, 93, 1 6, 120, 64, 93, 98, 112, 154, 167, 202, 211, 215, 225, 245, 273, 78, 289, 315, 324, 328, 59, 89, 93, 107, 149, 162, 197, 206, 211, 220, 241, 268, 273, 285, 310, 319, 324, 186, 174, 32, 93, 96, 216 243, 13, 74, 77, 197, 224, 7, 76, 93, 143, 169, 198, 247, 267, 27 5, -4, 39, 55, 93, 197, 328, 353, 186, 33, 67, 93, 206, 60, 63, 9 3, 165, 246, 298, 343, 49, 52, 82, 154, 235, 286, 331, 114, 172, 45, 61, 100, 80, 87, 93, 171, 288, -12, 63, 93, 102, 167, 241, 26 7, 279, 286, 289, 301, 326, -21, 55, 85, 93, 158, 233, 258, 270, 78, 280, 293, 318, 257, 264, 271, 285, 299, 343, 123, 134, 137, 1

```
In [315]: channelsExcerpt2, framerate, data = readAudioFileExcerpt('data/Break
    #write code to generate hashesExcerpt2
    for samples in channelsExcerpt2:
        hashesExcerpt2 = fingerprint(samples, Fs, wsize, wratio, fan_val
        dictExcerpt2 = hashesToDict(hashesExcerpt2)
        count2, delta_k2 = match_fingerprint(dictExcerpt2, dictOriginal)
    if delta_k2:
        fig = plt.figure()
        ax = fig.add_subplot(111)
        numBins = 10
        ax.hist(delta k2,numBins,color='green',alpha=0.8)
```



Exercise 5. Based on the number of matches (consider how many possible matches there are) and histogram of offsets, justify that your code produces a desirable result.

The code produces a correct result because the number of matches is much higher in the first graph and than the second graph, as can be seen from the histograph

Exercise 6. Now to test the system. Create your own dataset (of at least 100 songs) to test the accuracy of the Shazam system. You will need to generate a dictionary for each song. Use 10% of the songs in the dataset to test for recognition accuracy. Change the length of the hash (len_hash) (try several different values from 10 to 25) and amplitude threshold (amp_min) (try several different values from 5 to 10) and compare the accuracy, speed, and size of the dictionary. What do you think is the optimal trade-off?

Extra Credit. There is one component not yet implemented, which is reading the audio snippet from the microphone. This is not mandatory, but you can try it yourself if you have time. It is suggested to use <u>pyaudio (http://people.csail.mit.edu/hubert/pyaudio/)</u>.

```
def readAudioFileMp3(filename, limit= None):
In [238]:
              audiofile = AudioSegment.from mp3(filename)
              if limit:
                  audiofile = audiofile[:limit * 1000]
              data = np.fromstring(audiofile. data, np.int16)
              channels = []
              for chn in xrange(audiofile.channels):
                  channels.append(data[chn::audiofile.channels])
              return channels, audiofile.frame rate, audiofile
          def readAudioFileExcerptMp3(filename, lowLimit, highLimit):
              audiofile = AudioSegment.from mp3(filename)
              audiofile = audiofile[lowLimit * 1000:highLimit * 1000]
              data = np.fromstring(audiofile. data, np.int16)
              channels = []
              for chn in xrange(audiofile.channels):
                  channels.append(data[chn::audiofile.channels])
              return channels, audiofile.frame rate, audiofile
```

We will read in a test file and compare against an excerpt from itself and then an excerpt from another song


```
In [239]:
          # read test_file
          files = os.listdir('test_data')
          test file = files[0]
          name = 'test_data/' + test_file
          print name
          hashListAMP = [[] for i in range (11-5)]
          channels, framerate,data = readAudioFileMp3(name)
          Fs = 44100 \# sampling freq
          wsize = 4096 # window size
          wratio = 0.5 # overlap ratio
          fan value = 10 #number of target points in the frequency domain to p
          #amp min = 25 # minimum amplitude of the peak.
          plot = False
          i = 0
          x = 0
          for samples in channels:
              if x == 0:
                  x += 1
                   continue
              for amp min in xrange(5,11):
                   hashListAMP[i].append(fingerprint(samples, Fs, wsize, wratic
                   i += 1
```


An excerpt from itself:


```
In [241]:
          # write your code here.
          # read in the audio snippit from 40s to 50s
          name = 'test data/' + files[0]
          print name
          channelsExcerpt1, framerate, data = readAudioFileExcerptMp3(name,40,
          hashListAmpExcerpt1 = [[] for i in range(11-5)]
          # call the fingerprint function to generate the hashes.
          i = 0
          x = 0
          for samples in channelsExcerpt1:
              if x == 0:
                  x += 1
                  continue
              for amp min in xrange(5,11):
                  hashListAmpExcerpt1[i].append(fingerprint(samples, Fs, wsize
                  i += 1
```


test data/Battlefield.mp3


```
In [242]: dictExcerpts1 = [[] for i in range(11-5)]
for i in xrange(0,11-5):
    for hashes in hashListAmpExcerpt1[i]:
        dictExcerpts1[i].append(hashesToDict(hashes))
```

















An excerpt from a different song


```
In [245]:
          # write your code here.
          # read in the audio snippit from 30s to 40s
          name = 'test_data/' + files[1]
          print name
          channelsExcerpt2, framerate, data = readAudioFileExcerptMp3(name,30,
          hashListAmpExcerpt2 = [[] for i in range(11-5)]
          # call the fingerprint function to generate the hashes.
          i = 0
          x = 0
          plot = False
          for samples in channelsExcerpt2:
              if x == 0:
                  x += 1
                  continue
              for amp min in xrange(5,11):
                  hashListAmpExcerpt2[i].append(fingerprint(samples, Fs, wsize
                  i += 1
          dictExcerpts2 = [[] for i in range(11-5)]
          for i in xrange(0,11-5):
              for hashes in hashListAmpExcerpt2[i]:
                  dictExcerpts2[i].append(hashesToDict(hashes))
          for i in xrange (0,6):
              count2, delta k2 = match_fingerprint(dictExcerpts2[i][0], dictOr
              if delta k2:
                  fig = plt.figure()
                  plt.title("Amp_min = " + str(i + 5))
                  ax = fig.add subplot(111)
                  plt.grid()
                  numBins = 10
                  ax.hist(delta k2,numBins,color='green',alpha=0.8)
```


test_data/Be With You.mp3

















Amp_Min 5 is clearly the best as the peak with the highest matches is above 160, but the actual Amp_min doesn't really matter match even if we take false positives into account. We will use Amp min 5 to test for best len_hash

Now testing len_hash. We will again load in the original file with each of the hash between 10 to 26

```
In [247]: # read test file
          files = os.listdir('test_data')
          test_file = files[0]
          name = 'test_data/' + test_file
          print name
          hashListLength =[[] for i in range(26-10)]
          channels, framerate,data = readAudioFileMp3(name)
          Fs = 44100 \# sampling freq
          wsize = 4096 # window size
          wratio = 0.5 # overlap ratio
          fan value = 10 #number of target points in the frequency domain to p
          amp min = 5 # minimum amplitude of the peak.
          plot = False
          i = 0
          x = 0
          for samples in channels:
              if x == 0:
                  x += 1
                  continue
              for length h in xrange(10,26):
                  hashListLength[i].append(fingerprint(samples, Fs, wsize, wra
                  i += 1
          test data/Battlefield.mp3
  In [ ]: dictOriginalsHash = [[] for i in range(26-10)]
          for i in xrange(0,26-10):
              for hashes in hashListLength[i]:
                  dictOriginalsHash[i].append(hashesToDict(hashes))
```


Excerpt from same song:

```
In [256]: # write your code here.
          # read in the audio snippit from 40s to 50s
          name = 'test_data/' + files[0]
          print name
          channelsExcerpt1LEN, framerate, data = readAudioFileExcerptMp3(name,
          hashListLengthExcerpt1 = [[] for i in range(26-10)]
          # call the fingerprint function to generate the hashes.
          i = 0
          x = 0
          for samples in channelsExcerpt1LEN:
              if x == 0:
                  x += 1
                  continue
              for length h in xrange(10,26):
                  hashListLengthExcerpt1[i].append(fingerprint(samples, Fs, ws
                  i += 1
```

test_data/Battlefield.mp3

```
In [257]: dictExcerptsLength1 = [[] for i in range(26-10)]
for i in xrange(0,26-10):
    for hashes in hashListLengthExcerpt1[i]:
        dictExcerptsLength1[i].append(hashesToDict(hashes))
```


```
In [258]: for i in xrange (0,26-10):
    count2, delta_k2 = match_fingerprint(dictExcerptsLength1[i][0],
    if delta_k2:
        fig = plt.figure()
        plt.title("Hash_Len = " + str(i + 10))
        ax = fig.add_subplot(111)
        numBins = 10
        ax.hist(delta_k2,numBins,color='green',alpha=0.8)
```



Excerpt from different song:

```
In [261]:
          # write your code here.
          # read in the audio snippit from 40s to 50s
          name = 'test_data/' + files[1]
          print name
          channelsExcerpt2LEN, framerate, data = readAudioFileExcerptMp3(name,
          hashListLengthExcerpt2 = [[] for i in range(26-10)]
          # call the fingerprint function to generate the hashes.
          i = 0
          x = 0
          for samples in channelsExcerpt2LEN:
              if x == 0:
                  x += 1
                  continue
              for length_h in xrange(10,26):
                  hashListLengthExcerpt2[i].append(fingerprint(samples, Fs, ws
          dictExcerptsLength2 = [[] for i in range(26-10)]
          for i in xrange(0,26-10):
              for hashes in hashListLengthExcerpt2[i]:
                  dictExcerptsLength2[i].append(hashesToDict(hashes))
          for i in xrange (0,26-10):
              count2, delta_k2 = match_fingerprint(dictExcerptsLength2[i][0],
              if delta k2:
                  fig = plt.figure()
                  plt.title("Hash Len = " + str(i + 10))
                  ax = fig.add subplot(111)
                  numBins = 10
                  ax.hist(delta k2,numBins,color='green',alpha=0.8)
```

test_data/Be With You.mp3



Length of Hash doesn't seem to make too much difference either. As such, a lower length of hash is better as it reduces the size of the dictionary. Amp_Min and Len_hash don't visibly affect the speed either, although I'd hypothesize that a lower hash length and a higher peak would increase the speed

Creating a library of 50 dictionaries with amp_min = 5 and Len_hash = 10

```
In [263]:
          import os
          files = []
          for filename in os.listdir('test_data'):
              name = 'test data/' + filename
              print name
              channels, framerate,data = readAudioFileMp3(name)
              Fs = 44100 # sampling freq
              wsize = 4096 # window size
              wratio = 0.5 # overlap ratio
              fan_value = 10 #number of target points in the frequency domain
              amp min = 5 # minimum amplitude of the peak.
              plot = False
              for samples in channels:
                  hashes = fingerprint(samples, Fs, wsize, wratio, fan_value,
              dictCur = hashesToDict(hashes)
              fileHandle = open(filename +".fp","wb") #wb: write binary
              pickle.dump(dictCur, fileHandle)
              files.append(filename)
```

```
test data/Battlefield.mp3
test data/Be With You.mp3
test data/champion.mp3
test data/22. Before The End.mp3
test data/03 City of Safe Harbors.mp3
test data/Best I Ever Had-Drake.mp3
test data/13 At Anchor.mp3
test data/04001798.mp3
test data/02 Butterflies.mp3
test data/11 Arrival At Sydney Harbour.mp3
test data/Climax ft. Diplo.mp3
test data/Early birdie.mp3
test data/Church.mp3
test data/18. Danny's Blues.mp3
test data/01.mp3
test data/2b75f2a7d9f3ccc9c96b64ec688f86a1.mp3
test data/06 Elephant Island.mp3
test data/Clocks-Coldplay.mp3
test data/Back To New (3LAU Remix).mp3
test data/best in me.mp3
test data/24TheSaturdaysEgo.mp3
test data/preview.mp3
test data/13. Child.mp3
test data/Baby Its Cold Outside.mp3
test data/10 An Enchanted Evening.mp3
test data/Can't Help But Wait (Album Version).mp3
test data/owl.mp3
test data/Cobra-decentlydope.mp3
test data/breakdown.mp3
test data/2.mp3
test data/Earthquake.mp3
test data/453508.mp3
test_data/boston.mp3
test data/AZIATIX-Cold.mp3
test data/14 Come Thru.mp3
test data/Boyfriend (cover).mp3
test data/Drops.mp3
test data/dynamite.mp3
test data/Blind.mp3
test data/black eved pees-boom boom pow.mp3
test data/02-Soulja Boy - Bird Walk-RGF.mp3
test data/already taken.mp3
test data/Chasing Cars.mp3
test data/Beautiful.mp3
test data/BVAll.mp3
test data/concerning hobbits.mp3
test data/8115.mp3
test data/13192.mp3
test data/already gone.mp3
test data/Birthmark.mp3
```

```
def get excerpt dict(filename, low, high):
In [404]:
              all_files = os.listdir('test_data')
              name = 'test data/' + all files[files.index(filename)]
          #
               print name
              channels, framerate, data = readAudioFileExcerptMp3(name,low,high
              Fs = 44100 \# sampling freq
              wsize = 4096 # window size
              wratio = 0.5 # overlap ratio
              fan value = 10 #number of target points in the frequency domain
              amp min = 5 # minimum amplitude of the peak.
              plot = False
              for samples in channels:
                   hashes = fingerprint(samples, Fs, wsize, wratio, fan_value,
               return hashesToDict(hashes)
          def identify(excerptDict,OGDicts,filenames):
              cur max = 0
              i = 0
              for each dict in OGDicts:
                   count, delta k = match fingerprint(excerptDict, each dict)
                   if delta k:
                       #print count, delta k
                       n, b = np.histogram(delta_k,numBins)
                       print max(n)
          #
                       if cur max < np.amax(n):</pre>
                           cur max = np.amax(n)
                           right file = i
                   i += 1
              return filenames[right file]
          num songs = len(files)
In [364]:
          OriginalDicts = []
          for x in xrange(0,num songs):
              fileHandle = open(str(files[x]) +".fp","rb")
              OriginalDicts.append(pickle.load(fileHandle))
In [406]:
          low = 30
          high = 40
          test set = np.random.random integers(0,num songs-1,int(num songs *()))
          times correct = 0
          for each_song in test_set:
              song dict = get excerpt dict(files[each song],low,high)
              ID = identify(song dict,OriginalDicts,files)
              if ID == files[each song]:
                times correct+= 1
          print str((float(times correct)/len(test_set)*100)) + "% is our accu
```

100.0% is our accuracy

←